

Does your Bosch Tool

have a Li-Ion Battery?

If yes, please note to the following shipping instructions for Li-Ion batteries.

Does your battery have more or less than 100 Wh?

This specification can be found on the identification plate of your battery:



$\leq 100 \text{ Wh}$

- 1. Remove the battery from the tool. Is there any visible external damage? If yes, please call the Bosch Customer Contact Centre on 0344 736 0109* or email boschservicecentre@bosch.com
- 2. If no: Place the tool and the battery separately into the package.
- 3. Ensure that the terminals of battery and tool are not touching each other to avoid the danger of a short circuit and fire hazard.
- 4. Seal the package.
- 5. Print the label on page 2, cut it out and stick it onto the front side of the package. (Do not glue over the edges, on the sides or on the reverse of the package.)

> 100 Wh

These batteries are classified as dangerous goods for transportation under EU law and require special shipping arrangements.

Please call the Bosch Customer Contact Centre on 0344 736 0109* or email boschservicecentre@bosch.com for further details

^{*} Calls are charged at 4 pence per minute from a BT landline, call charges from other networks will vary and mobiles may be significantly more, please contact your service provider for further information



